


Read the instructions and keep them safe.




with CHILL INDICATOR

It's simple. Just fill the filter jug with water and put in fridge. As the water starts to chill the indicator turns blue.


Before using the filter jug for the first time

- 1 Remove all packaging from the filter jug.
- 2 Remove the jug lid and take the water tank out.
- 3 Take the filter cartridge out and remove any packaging.
- 4 Fill the filter jug with cold water and rinse.

Preparing the water filter cartridge



Prepare your Aqua Optima filter cartridge by carefully following all of the instructions on the packaging. Remove the Aqua Optima cartridge from all packaging. There may be a small residue of black particles (carbon) in the bag or adhering to the cartridge body, this is normal. These particles are harmless and are washed off during the preparation process.




Shake the Aqua Optima cartridge in cold water to ensure that any trapped air bubbles are removed. Some loose carbon particles may be released during this process. This is normal and does not influence performance. Your Aqua Optima filter cartridge is now ready for use.

Fitting the filter into the water tank



- 1 Remove the jug lid and lift the water tank out of the fridge jug.
- 2 Place the Aqua Optima cartridge into the base of the water tank.
- 3 Push the Aqua Optima cartridge towards the water tank and turn it clockwise to lock in place.
- 4 Ensure the Aqua Optima cartridge is firmly secured.
- 5 Lower the water tank until it sits inside the jug.
- 6 Replace the lid.



7 Important – Fill the upper vessel with cold water and allow the water to pass through the cartridge. Discard this water and repeat this process once more.


Your fridge jug is now ready for use.

Changing the water filter cartridge

- 1 Remove the jug lid.
- 2 Lift the water tank out of the jug.
- 3 Hold the water tank and turn the water filter anti-clockwise to release it from the water tank.
- 4 Discard the water filter.
- 5 Prepare and insert the new Aqua Optima cartridge for use as described opposite.

Filter cartridge life indicator

The cartridge life indicator dial can be found on the lid. This is to remind you when to change your Aqua Optima filter cartridge.



Aqua Optima 30-day Standard filter cartridge

To ensure the best performance of your Aqua Optima Standard cartridge, it should be changed after 100 litres, which is approximately 4 weeks for a typical family in a hard water area.

To remind you to do this every month (4 weeks) follow this example:-

- You have fitted your new Aqua Optima filter and it is now April – month 4.
- Then set the reminder dial to May – month 5.
- By looking at the reminder you can tell you need to change the water filter in May.

Aqua Optima 60-day Double Life filter cartridge

To ensure the best performance of your Aqua Optima Double Life cartridge, it should be changed after 200 litres, which is approximately 8 weeks for a typical family in a hard water area.

To remind you to do this every two months (8 weeks) follow this example:-

- You have fitted your new Aqua Optima filter and it is now April – month 4.
- Then set the reminder dial to June – month 6.
- By looking at the reminder you can tell you need to change the water filter in June.



Care of the System

Water is a foodstuff. We recommend that any treated water is consumed or discarded within 2 days. In the event of the filter jug not being used for more than 48 hours, fill it twice with cold water, and discard the water before continuing use as normal. Should the system not be used for an extended period of time (for example, a holiday) we recommend that the filter is removed and placed in a clean plastic bag and stored in the fridge. This will help to maintain the filter when not in use. Before using the filter after storage, follow the preparation and fitting instructions for use as normal.

The filter should be stored out of direct sunlight and away from heat sources.

The water tank and jug lid should be washed regularly, at least every time the filter is replaced

Cleaning

Wipe inside and out with a damp cloth and clean the water filter and tank. Don't use any washing-up liquid or anything that may taint the water.

Don't use harsh or abrasive cleaning agents or solvents.

Filter Holder Seal

Care should be taken to ensure that the seal is fitted correctly otherwise un-filtered water may leak into the filter jug. If the seal becomes dislodged during cleaning or transportation it can be easily re-fitted on to the filter holder found on the underside of the water tank

Important safeguards

- 1 Only filter cold water.
- 2 Consume filtered water within one to two days.
- 3 We recommend boiling water for use in the preparation of baby food.
- 4 Don't use the filter jug for any purpose other than filtering water.

ART_554 Rev 2

AQUA
OPTIMA[™]
PUREER WATER FAST

Aqua Optima
PO Box 3439
Chester
CH1 9DL
United Kingdom

Helpline +44 (0) 1624 829875

Email enquiries@aquaa-optima.com

www.aqua-optima.com

AQUA
OPTIMA[™]
PUREER WATER FAST

**REMOVES IMPURITIES FROM
YOUR TAP WATER**

Aqua Optima is a unique water filtration system that has been developed to deliver the purest filtered water quickly – removing high levels of herbicides, pesticides, lead, chlorine and limescale.



**with CHILL
INDICATOR**

INSTRUCTIONS

Model No. AO/FJ-LM-M1-07